



# Swings

## MANUAL

### ✓ COMPATIBLE WITH

- Yoga Swing
- Baby Swing
- Bounce Swing
- Nest Swing
- Seat Swing
- Wrecking Swing
- Monkey Swing

### PRE-INSTALLATION

#### If your Swing is packaged with 2 foam coverings:

Slip them over the 2 rope sections at the very top of your Swing.

#### If your Swing is packaged with 1 foam covering:

Slip it over the rope section at the very bottom of your Swing.

### INSTALLATION: YOGA AND NEST SWINGS

#### VULY MINI:

Remove the first set of carabiners and the Height Adjustment Straps on both sides of the Swing.

Unlock the carabiners on your Swing, and hook them into the lugs on the Swing Rail.

Ensure that both carabiners are facing the same direction and have been firmly tightened.

#### VULY MAX:

Unlock the carabiners on your Swing, and hook them into the lugs on the Swing Rail.

Ensure that both carabiners are facing the same direction and have been firmly tightened.

### INSTALLATION: BABY, BOUNCE, SEAT, WRECKING AND MONKEY SWINGS

Unlock the carabiners on your Swing, and hook them into the lugs on the Swing Rail.

Ensure that both carabiners are facing the same direction and have been firmly tightened.

### HEIGHT ADJUSTMENT (EXCL. MONKEY SWING)

**To lower:** Lift your Swing and feed the rope(s) up through the Height Adjustment Buckles until you reach the desired height.

**To raise:** Lift the top(s) of the Swing rope(s) and feed down through the Height Adjustment Buckles until you reach the desired height.

# CONGRATULATIONS!

You have attached your Swing onto your Vuly Swing Set.